



## SWM LCR P1.07 HANDRAIL ATTACHMENT (BY OTHERS)

STANDARD WATERMASTER LCR SYSTEM  
OPTIMUM WATERMASTER LCR SYSTEM

- NOTES:
1. See G 1.01 A, B or C for Drainage Options.
  2. See G 1.02 for termination Options.
  3. The Length of the Sleeve = Total thickness of the system
  4. The fastener and the construction to which it connects must be designed and installed to carry all of the loads on them without transferring any of those loads to the EIFS.

Disclaimer: The design, specifications, and construction shall comply with all local building codes and standards. Parex USA installation guidelines are for general information and guidance only and Parex USA specifically disclaims any liability for the use of this design, and for design, engineering, or workmanship of any project. The assembly shall be designed to prevent condensation within the assembly. The designer and the user shall provide final drawings and specifications. Products shown other than those manufactured by Parex USA are shown for clarity of the Parex USA product only. Contact the manufacturer of such other products for installation instructions.