



- PAREX USA WATER-RESISTIVE & AIR BARRIER COATING
- PAREX USA ADHESIVE
- EXPANDED POLYSTYRENE INSULATION BOARD
- PAREX USA BASECOAT
- PAREX USA REINFORCING MESH EMBEDDED IN PAREX USA BASECOAT
- PAREX USA PRIMER (OPTIONAL)
- PAREX USA FINISH
- PAREX USA MESH BACKWRAP ATTACHED W/ CORROSION RESISTANT STAPLES
- PAREX USA ADHESIVE
- CLOSED CELL BACKER ROD & ELASTOMERIC SEALANT (BY OTHERS) W/ WEEPS @ 16" O.C.

EXCESS DRAINEDGE™ REMOVED PRIOR TO INSTALLATION OF SEALANT

PAREX USA DRAINEDGE™

FLASHING W/ WATER TIGHT, UP-TURNED ENDS SET IN SEALANT. SLOPE FLASHING FOR DRAINAGE. SEAL BETWEEN FLASHING & FRAME.

PAREX USA SHEATHING TAPE EMBEDDED IN PAREX USA WATER-RESISTIVE & AIR BARRIER COATING

FRAME

## SWM W1.01 HEAD ASSEMBLY (WINDOW, DOOR, LOUVER VENTS, ETC.)

STANDARD WATERMASTER SYSTEM  
OPTIMUM WATERMASTER SYSTEM

- NOTES:
1. To ensure a continuous air barrier across the building envelope, a continuous air seal should be made at each substrate change, joints/gaps, penetrations and dissimilar material terminations. These must be a consideration of the designer in the overall wall assembly design.
  2. Do not use plastic window head flashing.

Disclaimer: The design, specifications, and construction shall comply with all local building codes and standards. Parex USA installation guidelines are for general information and guidance only and Parex USA specifically disclaims any liability for the use of this design, and for design, engineering, or workmanship of any project. The assembly shall be designed to prevent condensation within the assembly. The designer and the user shall provide final drawings and specifications. Products shown other than those manufactured by Parex USA are shown for clarity of the Parex USA product only. Contact the manufacturer of such other products for installation instructions.